

Image	Part No.	Works With Radio Models
	Motorola Solutions - M	Works With Motorola: BC10, BC90, BC120, BC130, BPR40, CLS1110, CLS1410, CP125, CP88, CP100, CP110, CP150, CP185, CP200, CP200D, CP200XLS, CP450, CT150, CT250, CT450, CT450LS, DTR Series, GP2000, GP300, GP308, GP68, GP88, GP2000, GTI, GTX, LTS2000, MAG ONE, PR400, P040, P080, P110, P1215, P1225LS, PRO3150, SP10, SP21, SP50, XTN446, XTN500, XTN600, XV1100, XV2100, XU1100, XU2100, XU2600, VL130, VL50, GP280, GP350 (requires Motorola adaptor HLN9482)
	Motorola Solutions - M3	Works With Motorola: GP900, GP9000, HT1000, JT1000, MT2000, MTS2000, MTX8000, MTX838, MTX900, MTX9000, MTX960, MTX-LS, XTS2500, XTS3000Astro, XTS3500, XTS5000, XTS3000, PR1 500, XTS1500, MX838
	Motorola Solutions - M4	Works With Motorola: GP1280, GP140, GP320, GP328, GP329, GP338, GP339, GP340, GP360, GP380, GP640, GP650, GP680, HT1250, HT-1250LS, HT1550, HT1550XLS, HT750, MTX8250, MTX8250LS, MTX850, MTX-850LS, MTX9250, MTX950, MTX950, PR860, MTP700, PRO5150, PRO5350, PRO5450, PRO5550, PRO5750, PRO7150, PRO7350, PRO7450, PRO7550, PRO9150, PTX700, PTX760, PTX780, PRO7750, WARIS
	Motorola Solutions - M5	Works With Motorola: EX500, EX560, EX560XLS, EX600, GL200, GL2000, GP328Plus, GP338Plus, GP344, GP388, Pro5150Elite, Pro7150, Pro9150, Elite7150, Elite9150

Image	Part No.	Works With Radio Models
	Motorola Solutions - M12	Works With Motorola: APX Series: APX4000, APX6000, APX7000, APX8000, APX NEXT DP3400, DP3401, DP3600, DP3601, DP4000 Series, SRX2200 XPR Series: XPR6300, XPR6350, XPR6380, XPR6500, XPR6550, XPR6580, XPR7350e, XPR7380e, XPR7550e, XPR7580e
	Motorola Solutions - M14	Works With Motorola: SL300, SL3000e, SL3500e, SL500, SL7000, SL7500, SL7550e, SL7580e, SL7590e, SL4000, SL4010 - WAVE TLK100
	Motorola Solutions - M15	Works With Motorola: DP2000, DP2400, DP2600, DP 3441MTP, 3100 / 3150 / 3200 / 3250 / 3500 / 3550, DP2400, DP2600, DP3441, MOTOTRBO - XPR3300e, XPR3500e
	Motorola Solutions - M20	Works with Motorola: APX N30, N50, N70, R7, Ion, MXP600, MTP600

Image	Part No.	Works With Radio Models
	Harris - HR2	Works with L3Harris: P5300 / 5400 / 5500 Series- P5350, P5370, P5450, P5470, P5550, P5570, P7300 Series - P7370, P7350, XG Series - XG-15P, XG-25P, XG-75P
	Harris - HR3	Works with L3Harris: XG100P, XL185P, XL200P
	HIROSE	Works with quick disconnect (HIROSE) Connectors. See our line of adaptors here.
	Icom - I4	Works with Icom: F3260, F3261D, F3360D, F3400D, F4261D, F3263, F4360D, F4400DT, F5400, F6400D, DS, F7010, F7020, F7040, F7210T, F9011, F9021, F52D, F62D, SAT-100
	Icom - S2B	Works with Icom: Network- IP100H, IP501H Aviation- A25


Image	Part No.	Works With Radio Models
	Icom - S3B	Works with Icom: IC-F1000 Series, IC-F2000 Series, IC-F1100D Series, IC-F2100D Series, IC-F3031S, IC-F3230DT/DS, IC-F4031S, IC-F4230DT/DS, IC-F31W/41W, V88. BearCom BC1000 - Waterproof
	Kenwood - K	Works with Kenwood: NEXEDGE/DMR- NX-1202/1302, NX-3220 / 3320 / 3420 DMR Only- TK-D240/TK-D340 Analog- TK-2312 / 3312, TK-2317 / 3317, TK-2360 / 3260, TK-2400 / 3400 ProTalk- TK-2400 / 3400, TK-3230DX
	Kenwood - K1	Works with Kenwood: NEXEDGE/DMR/P25- NX- 3200/3300, NX-5200 / 5300 / 5400 NEXEDGE Only- NX- 210G, NX-200G / 300 P25 Only- TK-5220 / 5320
	Sepura - SP2	Works with Sepura: SC230 Series, STP8000, STP9000, STP9100, STP9200
	Sonim - SN	Works with Sonim: XP5S, XP8

Image	Part No.	Works With Radio Models
	Tait - TA	Works with Tait: TP7100 / 8100 series, TP9300 / 9400 series, Harris TP3300 / TP3350, TP9500 / TP9600
	Vertex - Y6	Works with Vertex Standard Motorola Solutions: VTX-720, VDX720,VX820, VX821, VX824, VX829, VX871, VX874, VX879, VX920, VX921, VX924, VX971, VX974, VX979Y6
	Vertex - Y6	Works with Vertex Standard Motorola Solutions: VTX-720, VDX720,VX820, VX821, VX824, VX829, VX871, VX874, VX879, VX920, VX921, VX924, VX971, VX974, VX979Y6